

Eicher School Bus									
Labour Charge					Spare Parts				
	Description of Item (2)	Unit	Qty	Eastern Automobile Workshop		Description of Item (2)	Eastern Automobile Workshop		
1	Engine overhoulung	Each	1	8000	1	Accelerator cable	580		
2	Overhoulung cylinder head.	Each	1	3000	2	Air filter	2400		
3	Removal & Installation engine.	Each	1	2500	3	Air filter hose pipe	800		
4	Removal & replacement of rocker arm and push rod.	Each	1	800	4	Air unloader opening & new service kit fitting	1200		
5	Removal & replacement of turbocharger.	Each	1	1000	5	Alternator Assy	11300		
6	Removel & installation of engine piston ring.	Each	1	3500	6	Alternator carbon bush	150		
7	Fuel filters change	Each	1	100	7	Alternator cut out	950		
8	Oil filter cartridge & engine oil changing.	Each	1	200	8	Alternator Fan belt pully bearing	380		
9	Replacement of pistons Rings or connecting rods.	Each	1	3500	9	Alternator overhauling	650		
10	Removal and Re-installation of oil dip -stick tube.	Each	1	150	10	Alternator rectifile	1450		
11	Tightening of cylinder heads nuts	Each	1	500	11	Anabond GUM (Big)	90		
12	Replacement cylinder head gasket.	Each	1	2500	12	Anabond GUM (Small)	60		
13	Replacement cylinder head cover gasket.	Each	1	150	13	Axel lock	40		
14	Removal & Installation of oil cooler.	Each	1	350	14	Axel shaft	6500		
15	Removal & fitment of Oil sump gasket.	Each	1	500	15	Axel spacer	40		
16	Replacement of front engine mounting.	Each	1	150	16	Back bumper	2500		
17	Replacement of rear engine mounting.	Each	1	150	17	Back gear bearing	380		
18	Replacement of timing gear cover oil seal.	Each	1	350	18	Back glass	2500		
19	Removal & installation of Valve tappets .	Each	1	1200	19	Back light Assy (Left)	950		
20	Removal & installation of injector set.	Each	1	250	20	Back light Assy (Right)	950		
21	Removal & installation of Fuel injection pump -	Each	1	650	21	Back Light Bulb	20		
22	Removal & installation of Fuel feed pump .	Each	1	150	22	Battery (Amaron)	8500		

23	Removal & installation of High pressure lines / piece.	Each	1	150
24	Removal & replacement of air cleaner	Each	1	100
25	Removal & re-installation of exhaust manifold .	Each	1	450
26	Replace ment of Turbocharger.	Each	1	800
27	Removal & installation of Oil pump -	Each	1	500
28	Removal & installation of power steering pump.	Each	1	800
29	Replacement of power steering pump belt.	Each	1	250
30	Removal & re-installation of rear exhaust pipe	Each	1	150
31	Remove & instrallation of siclencer assy.	Each	1	400
32	Removal and re-installation of rear propeller shaft.	Each	1	150
33	Removal and re-installation of one universal joint cross.	Each	1	250
34	Replacement of transmission oil/gear oil	Each	1	200
35	Water servicing	Each	1	300
36	Adjustment of brake pedal free play.	Each	1	100
37	Complete brake bleeding and refilling brake fluid.	Each	1	150
38	Dismantling and assembling of top cover assy.	Each	1	250
39	Overhauling brake master cylinder assy.	Each	1	250
40	Overhauling clutch master cylinder assy.	Each	1	250
41	Overhauling of lower sleeve cylinder assy.	Each	1	200
42	Plalacement of brake caliper pin.	Each	1	150
43	Removal & fitment of parking brake leaver	Each	1	250
44	Removal & installation of accelerator cable.	Each	1	150
45	Removal & installation of Clutch master cylinder.	Each	1	200
46	Removal & installation of vacuum booster.	Each	1	300

23	Battery (Bosch)	7800
24	Battery box new making	550
25	Battery cable -ive	330
26	Battery cable +ive	330
27	Battery terminal end	80
29	Bearing 6202	230
30	Bearing 6302	230
31	Bendix pinion	1400
32	Benjo washer	5
33	Benzu Bolt	120
34	Black tape	20
35	Brake Booster	5500
36	Brake Booster Assy	8300
37	Brake Booster kit	710
38	Brake bucket	220
39	Brake Bucket Kit	150
40	Brake flexible pipe front	430
41	Brake fluid	120
42	Brake fluid dot3	175
43	brake light bulb	20
44	Brake light switch	230
45	Brake lining	350
46	Brake lining back and front	1250
47	Brake Oil	120

47	removal & re-installation of gear box and clutch. 4x4	Each	1	1500
48	Removal & replacement of speedometer drive gear.	Each	1	150
49	Removal and re-installation of accelerator pedal.	Each	1	100
50	Removal and re-installation of brake padel spring	Each	1	100
51	Removal and re-installation of Clutch padel spring	Each	1	100
52	Remove & installation of clutch ,pressure plate 2W	Each	1	1500
53	Removel & installation of fly wheel ring gear.	Each	1	900
54	Replacement of brake caliper assy.	Each	1	150
55	Replacement of brake pad (1 set)	Each	1	200
56	Replacement of Brake pipe/hose (1 No.).	Each	1	150
57	Replacement of brake shoes (1 set)	Each	1	350
58	Replacement of clutch fluid pipe.	Each	1	150
59	Replacement of Parking Brake Cable -Front.	Each	1	350
60	Replacement of Parking Brake Cable -Rear (1 No.).	Each	1	350
61	Removal and re-installation of one cross member.	Each	1	250
62	Removal and installation of spring bush per pice	Each	1	80
63	Removal & replacement of one shackle with pin & bushes.	Each	1	200
64	Removal and installation of one front spring.	Each	1	250
65	Removal and installation of one rear spring.	Each	1	300

48	Brake pipe (Rear)	450
49	brake pipe bleasting	100
50	Brake servo	12300
51	Brake Shoe	1800
52	Brake shoe	350
53	Brake shoe	350
54	Brake shoe lock with spring	180
55	Brass blezzing	100
56	Bulb 1016	20
57	Bulb 1141	20
58	Bulb 67	15
59	Bumper indicator light assy	380
60	bush stabilzer	280
61	Cam shaft	6700
62	Cam Shaft Bearing	1650
63	Cam shaft bush	320
64	Cam shaft gear	620
65	Carbon bush 12 v	230
66	Carbon holder	1280

66	Removal & replacement of spring eye bush/matel bush	Each	1	250
67	Removal and replacement of front shockabsovr	Each	1	50
68	Removal and replacement of rear shockabsovr	Each	1	50
69	Removal & tempering spring front	Each	1	650
70	Removal & tempering spring rear	Each	1	850
71	Removal and installation of front axle tube 4X4 .	Each	1	1200
72	Removal and installation of front axle tube 2WD.	Each	1	800
73	Removal & installation of 4x4 drive shaft	Each	1	300
74	Removal & replacement of knucle ball change	Each	1	150
75	Removal & installation of front hub.	Each	1	250
76	Removal & fitment of tie rod.	Each	1	200
77	Removel & fitment of hub greasing	Each	1	350
78	Removal & fitment of wheel bearing	Each	1	250
79	Removal & installation of rear axle shaft.	Each	1	350
80	Removal & placement of tail pinion bearings outer.	Each	1	300
81	Removal & placement of tail pinion bearings inner.	Each	1	800
82	Removal & replacement of crown tail assy.	Each	1	1200
83	Removal & replacement of wheel nut and bolts.	Each	1	200
84	Replacement of rear axle oil seal.	Each	1	250
85	Replacement of tail pinion oil seal.	Each	1	300
86	Removel & fitment of hub greasing	Each	1	250
87	Removal & fitment of power steering pump .	Each	1	300
88	Removal & installation of power steering gear box.	Each	1	500

67	Carbon rocker 12v	1200
68	Carbon soldering	100
69	Center Bolt	120
70	Center lock	800
71	Center lock remote key	500
72	Check nut front	220
73	Check nut lock	150
74	Clamp for pipe	50
75	Clutch cylinder (lower)	1850
76	Clutch cylinder (Upper)	1950
77	Clutch cylinder Assy	250
78	Clutch cylinder kit	280
79	Clutch Cylinder Lower	1850
80	Clutch Cylinder Upper	1950
81	Clutch kit	50
82	Clutch Plate	4885
83	Clutch relese bearing	1600
84	Clutch rod	280
85	Connecting Bearing	1800
86	Connecting bearing	225
87	Connecting bush	200
88	Connecting rod	750
89	Connection Rod	2950

89	Removal and installation of mechanical steering box	Each	1	350
90	Repairing power steering rag assy.	Each	1	350
91	Replacement of power sreering oil seal	Each	1	1000
92	Replacement of steering column braket.	Each	1	450
93	Replacement of power steering pump belt.	Each	1	100
94	Replacement of drag link.	Each	1	300
95	Replacement of power strg hose.	Each	1	200
96	Replacement of steering wheel.	Each	1	150
97	Replacement of steering UJ cross.	Each	1	250
98	Changing fuel filters.	Each	1	200
99	Removal & instrallation of high pressure lines / piece.	Each	1	450
100	Removal & Setting FIP timing.	Each	1	450
101	Removal and installation of fuel line pipe	Each	1	400
102	Removal and re-installation of fuel flexible pipes.	Each	1	50
103	Removal and re-installation of fuel return line.	Each	1	300
104	Removal and re-installation of one fuel tank.	Each	1	800
105	Removal and re-installation of fuel retrun pipe.	Each	1	350
106	Removal, cleaning and installation of fuel filter	Each	1	150
107	Replacement air cleaner.	Each	1	100
108	Removal & installation of radiator condencer	Each	1	400
109	Removal & installation of fan shroud and radiator assy.	Each	1	300
110	Removal and re-installation of radiator.	Each	1	300
111	Replacement of Upper water hose.	Each	1	50
112	Replacement of Lower water hose.	Each	1	100
113	Removal & restallation of fan assy.	Each	1	150
114	Replacement of fan-Belt.	Each	1	100

90	Controlling cylinder Assy	600
91	Controlling overhauling	350
92	Controlling pipe	320
93	Controlling switch Assy	3200
94	Coolant	280
95	Crank shaft	18000
96	Crank shaft oil seal	1200
97	Cross Bearing	1450
98	Cross bearing	1450
99	Cross holder	2100
100	Cross propeller shaft	1200
101	Crown & Tail Assy	18000
102	Crown Overhauling	1800
103	Cycle pin	220
104	Dashboard polish	250
105	Dial wrench (6-32mm)	1000
106	Diesel filter	280
107	distilled water	30
108	Door agrnish inner	380
109	Door agrnish outer	380
110	Door lock new making	200
111	Drag link kit	1250
112	Drain plug	40
113	Dual brake valve Assy	3400
114	Dust Guard	400
115	Dust guard back and front	900

115	Adjustment of fan-Belt tension.	Each	1	300
116	Removal & replacement of thermostat valve.	Each	1	100
117	Remove & installation of Water pump.	Each	1	500
118	Checking specific gravity & Battery charge	Each	1	100
119	Removing & re-installation battery / batteries.	Each	1	50
120	Replacement of ammeter.	Each	1	350
121	Replacement of Boost pressure / air temperature sensor.	Each	1	50
122	Replacement of brake light switch.	Each	1	50
123	Replacement of Clutch switch.	Each	1	50
124	Replacement of combination switch.	Each	1	250
125	Replacement of Coolant temperature sensor.	Each	1	100
126	Replacement of ECU.	Each	1	200
127	Replacement of Engine speed sensor.	Each	1	200
128	Replacement of flasher unit.	Each	1	100
129	Replacement of front indicator.	Each	1	50
130	Replacement of horn.	Each	1	100
131	Replacement of main line switch.	Each	1	350
132	Replacement of oil pressure switch.	Each	1	150
133	Replacement of tail lamp.	Each	1	100
134	Replacement of wiper blade.	Each	1	20
135	Replacement waper motor.	Each	1	250
136	Removel & replacement of starter pinion	Each	1	350
137	Overhauling of starter motor.	Each	1	650
138	Removal and re-installation of alternator.	Each	1	300
139	Overhauling of alternator.	Each	1	500
140	Fitting seat cover	Each	1	500
141	Fixing of front / rear tyre mud flap set.	Each	1	200
142	Removal and installation of bumper assembly.	Each	1	500
143	Removal and installation of door lock.	Each	1	200

116	Dynamo bearing	220
117	Dynamo rocker	620
118	E/ paper	20
119	Electric horn 2v	420
120	Electric welding	50
121	Element Assy, Fuel	280
122	EML life max oil	380
123	Engine Bolt	120
124	Engine head assy	2100
125	Engine head gasket	1700
126	Engine mounting	650
127	Engine oil 15w40	350
128	Engine Oil Filter	250
129	Engine oil seal	350
130	Engine pacing	150
131	Engine ring	850
132	Engine Twining	100
133	Engine valve intake	300
134	Exhaust manifold	2400
135	Fan belt	650
136	Feed Pump	350
137	Feed pump Assy	1750
138	Flate washer	30
139	Fly wheel	4800
140	Fly wheel ring	1150
141	Fog Light	1200
142	foot mat	1600
143	Front bumper	5800
144	Front hub bearing inner	1300

144	Removal and installation of driver seat.	Each	1	100
145	Removal and installation of one fender	Each	1	150
146	Remove / replace of hood ceiling.	Each	1	1200
147	Removel & replacement of dash board.	Each	1	3000
148	Removel & replacement of inner view mirror.	Each	1	50
149	Removel & replacement of out side rear view mirror.	Each	1	100
150	Removel & replacement of sunvisor.	Each	1	50
151	Replacement of body shield complete	Each	1	2000
152	Replacement of body side indicator cover.	Each	1	50
153	Replacement of body side indicator lamp.	Each	1	50
154	Replacement of bonnet cable.	Each	1	150
155	Replacement of bonnet lock.	Each	1	150
156	Replacement of Bonnet.	Each	1	350
157	Replacement of cargo box locks.	Each	1	250
158	Replacement of cargo box.	Each	1	500
159	Replacement of door handle.	Each	1	50
160	Replacement of door hinges.	Each	1	150
161	Replacement of door weather strip.	Each	1	50
162	Replacement of fog lamp assy.	Each	1	500
163	Replacement of front bumper	Each	1	500
164	Replacement of license plate cover.	Each	1	100
165	Replacement of rear bumper	Each	1	400
166	Replacement of rear view mirror.	Each	1	100
167	Replacement of window regulator.	Each	1	250
168	Replacement of windscreen glass gum type	Each	1	2500
169	Replacement of windscreen glass rubber type	Each	1	400
170	Apron painting each	Each	1	200
171	Bonnet assy. Painting charges	Each	1	3000
172	Cabin assy. Painting charges	Each	1	13000

145	Front hub bearing outer	1100
146	Front Windshield glass	12500
147	fuel and water separator	250
148	Fuel filter	250
149	Fuel injection overflow pipe	320
150	Fuel injector nozzel	950
151	Fuel injector pipe	450
152	fuel pipe	320
153	Fuel pump washer	10
154	Fuel strainer A/B	250
155	Fuel Supply Pump	1200
156	Full Engine Overhauling	7000
157	Fuse	20
158	Fuse 10 Amp	10
159	Fuse 15 Amp	10
160	Fuse 20 Amp	10
161	Fuse 25 Amp	20
162	Fuse 30 Amp	15
163	Fuse 5 Amp	10
164	Gas kit	50
28	Gear Box	22000
165	Gear box assembly	22000
166	Gear box mounting	900
167	Gear box oil seal front	250
168	Gear box oile seal rear	1200
169	Gear box packing	330
170	Gear counter	6700
171	Gear oil	380
172	Gear pinion	600

173	Cargo box complete painting (double cabin)	Each	1	4000
174	Cargo box complete painting (single cabin)	Each	1	25
175	Cargo box side panting each	Each	1	2500
176	Cargo box tail gate painting	Each	1	1500
177	Complete body assy. Painting charges	Each	1	22000
178	Complete top panel painting charges	Each	1	4000
179	Door painting each	Each	1	2500
180	Front bumper assy. Painting charges	Each	1	2500
181	Lower panel painting each	Each	1	1500
182	Rear bumper painting charges	Each	1	1200
183	Side fander assy. Painting each charges	Each	1	2500
184	Tail gate/dicky painting charges	Each	1	2500
185	Apron painting each	Each	1	25
186	Bonnet assy. Painting charges	Each	1	3200
187	Cabin assy. Painting charges	Each	1	13000
188	Cargo box complete painting (double cabin)	Each	1	4000
189	Cargo box complete painting (single cabin)	Each	1	25
190	Cargo box side panting each	Each	1	2500
191	Cargo box tail gate painting	Each	1	2500
192	Complete body assy. Painting charges	Each	1	22000
193	Complete top panel painting charges	Each	1	3500
194	Door painting each	Each	1	2500
195	Front bumper assy. Painting charges	Each	1	2500
196	Lower panel painting each	Each	1	1500
197	Rear bumper painting charges	Each	1	1200
198	Side fander assy. Painting each charges	Each	1	2500
199	Tail gate/dicky painting charges	Each	1	2000

173	Gear pinion 2nd	1200
174	Gear pinion shaft	1450
175	Grease	500
176	Grease gun	1100
177	Half Engine Overhauling	3500
178	Hand Brake Cable	750
179	Hand brake cable	450
180	Head Gasket	1700
181	Head light Assy (Left)	1250
182	Head light Assy (Right)	1250
183	Head Light Bulb	120
184	Head light bulb	250
185	Head light bulb (Halogen)	220
186	Head light cover	500
187	Head light Set	1450
188	Horn and switch	350
189	Horn high	550
190	Horn low	420
191	Horn relay	120
192	horn switch	90
193	Hose pipe clamp	40
194	Hub Bearing Front Inner	1450
195	Hub Bearing Front Outer	750
196	Hub Check Nut	150
197	Hub greasing (Front)	450
198	Hub greasing (Rear)	450
199	Hub Oil Seal	220
200	Hub Splender	450
201	Hubs bearing	600
202	Hubs checknut	80



203	Hubs checknut lock	70
204	Hubs oil	80
205	Hubs oil seal front	200
206	Hubs oil seal rear	220
207	Hydraulic jack (Heavy Duty)	3500
208	Hydraulic jack (Light Duty)	2200
209	Hydraulic jack oil seal (Set of 12 pcs)	250
210	Hydraulic oil	250
211	Hydraulic pipe	90
212	Ignition switch	2700
213	Indicator light	180
214	Inner door lock (R )	270
215	Inner door lock(L)	270
216	Intake manifold	2100
217	Intake valve	1850
218	Jack lever	1050
219	Key Lock Set	380
220	Kilimeter cable	650
221	Kimpin Bearing	250
222	King Pin Bearing	580
	King pin bush machinery cutting	
223	bothr side	650
224	King pin kit	480
225	King pin overhauling bothside	550
226	Lock pati	10
227	Looking glass ( R )	400
228	Looking glass (L)	400
229	LT wire 5mm	25
230	LT wire 6mm	20

231	LT wire 8mm	50
232	Main Bearing	2100
233	Main bearing	250
234	Main Bearing Oil Seal	380
235	Main leaf spring ( R)	2100
236	Main leaf spring (F)	2000
237	Master cylinder	3200
238	Master Cylinder Kit	380
239	Master cylinder kit	380
240	Mobile	350
241	Mobile (15w40)	380
242	Mobile Filter	280
243	nozzle pipe	220
244	Number Plate	350
245	Nut & Bolts	10
246	Nuts and Bolts(4 Wheel)	50
247	Oil filter	250
248	Oil seal	40
249	Oil Supply Pump	900
250	Open end wrench set (6-32mm)	1200
251	Pilot bearing	600
252	Piston	2100
253	Piston	525
254	Piston Ring	3100
255	Plastic lock	20
256	Plastic tape	20
257	Plastic washer	10
258	Power steering bearing	450
259	Power Steering Belt	650
260	Power steering box Assy	5800

261	Power Steering Oil	330
262	Power steering overhauling	1200
263	Power steering pipe	200
264	Pressure plate	5500
265	Propeller shaft	2900
266	Propeller shaft bolt	40
267	PVC tape	20
268	Radiator assy	12300
269	Radiator cap	220
270	Radiator coolant	240
271	radiator hose pipe lower	420
272	Radiator hose pipe upper	420
273	Rain guard	1250
274	Rear center bolt	120
275	Rear Differential Assy	22000
276	Rear hub bearing inner	1300
277	Rear hub bearing outer	1200
278	Rear second leap	1850
279	Rear shackle Assy	450
280	Rear shackle pin	250
281	rear shocker	1580
282	recovery van hiring charges	1000
283	Rectifier	1220
284	Red paper	20
285	Relay 2 pin 12v	90
286	Relay 3 pin 12v	90
287	Relay 4 pin 12v	180
288	Relay 5 pin 12v	180
289	Release Bearing	1450
290	Relese bearing fork	990

291	Relese bearing lock	60
292	Rocker Arm	630
293	Rocker shaft	1600
294	Rotor coil	1250
295	Screw	10
296	seat cover	16000
297	Seat new making	2500
298	Self Armerture 12v	3800
299	Self bush 12V	40
300	Self Carbon	480
301	Self carbon 12V	120
302	Self field coil 12v	950
303	Self housing	1250
304	Self Overhauling	450
305	Self rewinding	450
306	Self top cover	320
307	Shaft yoke & Teeth	3300
308	Shakle Pin Assy	450
309	Shock absorber	1250
310	Shock Absorber Bush	50
311	Shock Absover Front	1450
312	Shock Absover Rear	1480
313	shocker bush	80
314	Shocker Front	1450
315	Shocker nut bolt	80
316	Side Light	120
317	Side Light Bulb	20
318	Side Light Clamp	50
319	Silencer box	2500
320	Silencer pipe	1800

321	Socket (6mm-32mm)	4400
322	Solonoid switch 12v	1350
323	Speedo meter Assy	1450
324	Speedo meter cable	600
325	Speedo meter pinion	80
326	Spring 2nd leaf (F)	1800
327	Spring 2nd leaf (R)	2100
328	Spring 3rd leaf (F)	1450
329	Spring 3rd leaf ®	1550
330	Spring 4th leaf (F)	1000
331	Spring 4th leaf ®	1200
332	Spring 5th leaf (F)	950
333	Spring 5th leaf ®	1150
334	Spring 6th leaf (F)	800
335	Spring 6th leaf ®	900
336	Spring buffer mounting	380
337	Spring bush	180
338	Spring Bush Metal	380
339	Spring Clamp	250
340	Spring cycle pin	550
341	Spring griping washer	50
342	Spring hanger	1650
343	Spring pin	280
344	Spring plate	580
345	Spring shackle	780
346	Spring washer	50
347	Starter carbon	120
348	Starter coil	1450
349	Starter relay 12v	220
350	Steering adjuster bolt assy	80

351	Steering box oil seal	80
352	Steering box overhauling	1200
353	Steering column (Inner)	450
354	Steering column (Outer)	450
355	Steering cross	1600
356	Steering cross bearing	450
357	Steering wheel cover	650
358	Sycronizer circlip lock	150
359	Sycronizer hub	1850
360	Sycronizer lock	200
361	Sycronizer ring	750
362	Sycronizer sheeve	650
363	Sycronizer sheeve inddle bearing	350
364	Tail Inner Bearing	1650
365	Tail Oil Seal	250
366	Tail Outer Bearing	1550
367	Tail pinion bearing inner	1450
368	Tail pinion bearing outer	1450
369	Tail pinion chechnut washer	60
370	Tail pinion checknut	130
371	Tail Pinion oil seal	500
372	Tappid cover packing	180
373	Tempering spring	100
374	Threading tape	20
375	Thrust washer	280
376	Tie clip	20
377	Tie rod end	1100
378	Tie Rod End-Big	850
379	Tie Rod End-Small	650
380	Tie rod kit	1280

381	Timing cover front	220
382	Timing cover gear	180
383	Timing cover oil seal	650
384	Timing pinion chain and adjuster kit set	380
385	Top shaft bearing	720
386	Transmission half over hauling	800
387	Transmission over hauling	1600
388	U bolt front	550
389	U bolt nut	40
390	U bolt rear	600
391	U bolt rear	600
392	U-Bolt	200
393	UJ cross	200
394	Valve guide	720
395	Valve key	40
396	valve oil seal	180
397	Valve spring	80
398	Valve washer	40
399	water pump Assy	3600
400	Wheel alignment	250
401	Wheel Bearing	650
402	Wheel bearing inner front	700
403	Wheel bearing inner rear	650
404	Wheel bearing oil seal inner front	120
405	Wheel bearing oil seal inner rear	100
406	Wheel bearing outer front	450
407	Wheel bearing outer rear	850
408	Wheel bolt	350
409	Wheel Cylinder Assy	1200

410	Wheel cylinder bucket	150
411	wheel Drum	3700
412	Wheel nut	150
413	Wheel wrench	820
414	Wind shield replacing	3000
415	Window glass	1500
416	Wiper Arm	350
417	Wiper Blade	500
418	Wiper blade	300
419	Wiper blade Assy	220
420	Wiper motor Assy	2800
421	Wiring clip	5
422	Zip cock	10