

Mahindra Scorpio Ambulance									
Spare Parts					Labour Charge				
	Description of Item (2)	Unit	Qty	Eastern Automobile Workshop		Description of Item (2)	Eastern Automobile Workshop		
1	A/C filter	per piece	1	630	1	Engine overhoulung	8000		
2	AC Belt	Pcs	1	750	2	Overhoulung cylinder head.	3000		
3	Accelerator cable	Each	1	380	3	Removal & Installation engine.	2500		
4	Accelerator cable assy	Each	1	380	4	Removal & replacement of rocker arm and push rod.	800		
5	Air filter	Each	1	620	5	Removal & replacement of turbocharger.	1000		
6	Air filter hose pipe	Each	1	420	6	Removel & installation of engine piston ring.	3500		
7	Alternator Assy	Each	1	10300	7	Fuel filters change	100		
8	Alternator carbon bush	Each	1	230	8	Oil filter cartridge & engine oil changing.	200		
9	Alternator cut out	Each	1	750	9	Replacement of pistons Rings or connecting rods.	3500		
10	Alternator Fan belt pully bearing	Each	1	380	10	Removal and Re-installation of oil dip -stick tube.	150		
11	Alternator overhauling	Each	1	450	11	Tightening of cylinder heads nuts	500		
12	Alternator rectifile	Each	1	1200	12	Replacement cylinder head gasket.	2500		
13	Anabond	No	1	40	13	Replacement cylinder head cover gasket.	150		
14	Anabond GUM (Big)	Each	1	90	14	Removal & Installation of oil cooler.	350		
15	Anabond GUM (Small)	Each	1	60	15	Removal & fitment of Oil sump gasket.	500		

16	Arm Bush Lower	Set	1	440
17	Arm Bush Upper	Set	1	440
18	Arm bushing	Each	1	350
19	Arm bushing lower big	Each	1	1200
20	Arm bushing lower small	Each	1	950
21	Arm Lower	set	1	7500
22	Arm Upper	Set	1	3800
23	Axel lock	Each	1	90
24	Axel shaft	Each	1	3800
25	Axel shaft oil seal	Each	1	280
26	Axel spacer	Each	1	150
27	Axle	Set	1	6800
28	Axle Oil Seal Outer	No	1	200
29	Axle Tube Oil Seal	No	1	150
30	Back bumper	Each	1	2150

16	Replacement of front engine mounting.	150
17	Replacement of rear engine mounting.	150
18	Replacement of timing gear cover oil seal.	350
19	Removal & installation of Valve tappets .	1200
20	Removal & installation of injector set.	250
21	Removal & installation of Fuel injection pump -	650
22	Removal & installation of Fuel feed pump .	150
23	Removal & installation of High pressure lines / piece.	150
24	Removal & replacement of air cleaner	100
25	Removal & re-installation of exhaust manifold .	450
26	Replace ment of Turbocharger.	800
27	Removal & installation of Oil pump -	500
28	Removal & installation of power steering pump.	800
29	Replacement of power steering pump belt.	250
30	Removal & re-installation of rear exhaust pipe	150

31	Back gear bearing	Each	1	230
32	Back glass	Each	1	2700
33	Back light Assy (Left)	Each	1	920
34	Back light Assy (Right)	Each	1	920
35	Back Light Bulb	No	1	20
36	ball joint	per piece	1	850
37	Ball Joint Lower	Set	1	980
38	Ball Joint Upper	Set	1	900
39	Battery (Amaron)	Each	1	8500
40	Battery (Bosch)	Each	1	7800
41	Battery box new making	Each	1	550
42	Battery cable -ive	Each	1	230
43	Battery cable +ive	Each	1	230
44	Battery terminal end	Each	1	100
45	Bearing 6202	Each	1	230
46	Bearing 6302	Each	1	230

31	Remove & installation of silencer assy.	400
32	Removal and re-installation of rear propeller shaft.	150
33	Removal and re-installation of one universal joint cross.	250
34	Replacement of transmission oil/gear oil	200
35	Water servicing	300
36	Adjustment of brake pedal free play.	100
37	Complete brake bleeding and refilling brake fluid.	150
38	Dismantling and assembling of top cover assy.	250
39	Overhauling brake master cylinder assy.	250
40	Overhauling clutch master cylinder assy.	250
41	Overhauling of lower sleeve cylinder assy.	200
42	Plalacement of brake caliper pin.	150
43	Removal & fitment of parking brake lever	250
44	Removal & installation of accelerator cable.	150
45	Removal & installation of Clutch master cylinder.	200
46	Removal & installation of vacuum booster.	300

47	Belt power string A/B	Each	1	450
48	Bendix pinion	Each	1	980
49	Benjo washer	Each	1	5
50	Benzu Bolt	Each	1	150
51	Black tape	per piece	1	25
52	Brake Booster	No	1	9500
53	Brake Booster Assy	Each	1	13500
54	Brake Booster kit	Each	1	520
55	Brake bucket	Each	1	120
56	Brake Bucket Kit	Set	1	150
57	Brake calliper lock	Each	1	120
58	brake disc	Each	1	3250
59	Brake flexible pipe front	Each	1	330
60	Brake fluid	Each	1	120
61	Brake fluid dot3	Each	1	100
62	Brake Hub Front	Set	1	3300

47	removal & re-installation of gear box and clutch. 4x4	1500
48	Removal & replacement of speedometer drive gear.	150
49	Removal and re-installation of accelerator pedal.	100
50	Removal and re-installation of brake padel spring	100
51	Removal and re-installation of Clutch padel spring	100
52	Remove & installation of clutch ,pressure plate 2W	1500
53	Removel & installation of fly wheel ring gear.	900
54	Replacement of brake caliper assy.	150
55	Replacement of brake pad (1 set)	200
56	Replacement of Brake pipe/hose (1 No.).	150
57	Replacement of brake shoes (1 set)	350
58	Replacement of clutch fluid pipe.	150
59	Replacement of Parking Brake Cable -Front.	350
60	Replacement of Parking Brake Cable -Rear (1 No.).	350
61	Removal and re-installation of one cross member.	250
62	Removal and installation of spring bush per pice	80

63	brake light bulb	per piece	1	20
64	Brake light switch	Each	1	250
65	Brake Oil	Lts	1	175
66	Brake Pad	Set	1	1400
67	Brake pad	Each	1	350
68	Brake pipe (Rear)	Each	1	320
69	brake pipe bleasting	each	1	100
70	Brake Shoe	Set	1	4800
71	Brake shoe	Each	1	950
72	Brake shoe lock with spring	Each	1	80
73	Brass blezzing	Each	1	50
74	Bulb 1016	Each	1	20
75	Bulb 1141	Each	1	15
76	Bulb 67	Each	1	15
77	Bumper indicator light assy	Each	1	350
78	bush stabilzer	per piece	1	90

63	Removal & replacement of one shackle with pin & bushes.	200
64	Removal and installation of one front spring.	250
65	Removal and installation of one rear spring.	300
66	Removal & replacement of spring eye bush/matel bush	250
67	Removal and replacement of front shockabsovr	50
68	Removal and replacement of rear shockabsovr	50
69	Removal & tempering spring front	650
70	Removal & tempering spring rear	850
71	Removal and installation of front axle tube 4X4 .	1200
72	Removal and installation of front axle tube 2WD.	800
73	Removal & installation of 4x4 drive shaft	300
74	Removal & replacement of knucle ball change	150
75	Removal & installation of front hub.	250
76	Removal & fitment of tie rod.	200
77	Removel & fitment of hub greasing	350
78	Removal & fitment of wheel bearing	250

79	C.V joint	per piece	1	1900
80	Cam shaft	Each	1	2750
81	Cam Shaft Bearing	Set	1	300
82	Cam shaft bush	Each	1	420
83	Cam shaft gear	Each	1	220
84	Carbon bush 12 v	Each	1	90
85	Carbon holder	Each	1	1250
86	Carbon rocker 12v	Each	1	730
87	Carbon soldering	Each	1	100
88	Center Bolt	No	1	80
89	Center lock	Each	1	500
90	Center lock remote key	Each	1	2500
91	Check nut front	Each	1	280
92	Check nut lock	No	1	200
93	Clamp for pipe	Each	1	40
94	Clutch cylinder (lower)	Each	1	2800

79	Removal & installation of rear axle shaft.	350
80	Removal & placement of tail pinion bearings outer.	300
81	Removal & placement of tail pinion bearings inner.	800
82	Removal & replacement of crown tail assy.	1200
83	Removal & replacement of wheel nut and bolts.	200
84	Replacement of rear axle oil seal.	250
85	Replacement of tail pinion oil seal.	300
86	Removal & fitment of hub greasing	250
87	Removal & fitment of power steering pump .	300
88	Removal & installation of power steering gear box.	500
89	Removal and installation of mechanical steering box	350
90	Repairing power steering rag assy.	350
91	Replacement of power steering oil seal	1000
92	Replacement of steering column bracket.	450
93	Replacement of power steering pump belt.	100
94	Replacement of drag link.	300

95	Clutch cylinder (Upper)	Each	1	2200
96	Clutch cylinder Assy	Each	1	200
97	Clutch cylinder kit	Each	1	230
98	Clutch kit	Each	1	230
99	Clutch kit box	Each	1	230
100	Clutch Plate	Set	1	4750
101	Clutch relese bearing	Each	1	1200
102	Clutch rod	Each	1	90
103	Connecting Bearing	Set	1	2200
104	Connecting bearing	Each	1	275
105	Connecting bush	Each	1	250
106	Connection Rod	Set	1	2400
107	Coolant	per litres	1	280
108	Crank Shaft	set	1	14200
109	Crank shaft oil seal	Each	1	930
110	Cross Bearing	set	1	650
111	Cross bearing	Each	1	650
112	Cross holder	Each	1	1120

95	Replacement of power strg hose.	200
96	Replacement of steering wheel.	150
97	Replacement of steering UJ cross.	250
98	Changing fuel filters.	200
99	Removal & instrallation of high pressure lines / piece.	450
100	Removal & Setting FIP timing.	450
101	Removal and installation of fuel line pipe	400
102	Removal and re-installation of fuel flexible pipes.	50
103	Removal and re-installation of fuel return line.	300
104	Removal and re-installation of one fuel tank.	800
105	Removal and re-installation of fuel retrun pipe.	350
106	Removal, cleaning and installation of fuel filter	150
107	Replacement air cleaner.	100
108	Removal & installation of radiator condencer	400
109	Removal & installation of fan shroud and radiator assy.	300
110	Removal and re-installation of radiator.	300
111	Replacement of Upper water hose.	50
112	Replacement of Lower water hose.	100

113	Cross propeller shaft	Each	1	620
114	Crown & Tail Assy	Set	1	8500
115	Crown Overhauling	Each	1	1800
116	CV Joint Assembly	set	1	4500
117	Cycle pin	Each	1	220
118	Dashboard polish	each	1	230
119	Dial wrench (6-32mm)	Set	1	1050
120	Diesel filter	Each	1	180
121	distilled water	per litre	1	25
122	Door agrnish inner	Each	1	250
123	Door agrnish outer	Each	1	250
124	Door lock new making	Each	1	250
125	Drain plug	Each	1	70
126	Dust Guard	Pcs	1	300
127	Dust guard back and front	Set	1	1200
128	Dynamo bearing	Each	1	230
129	Dynamo rocker	Each	1	230
130	E/ paper	Each	1	20
131	EGR pipe	Each	1	1850

113	Removal & restallation of fan assy.	150
114	Replacement of fan-Belt.	100
115	Adjustment of fan-Belt tension.	300
116	Removal & replacement of thermostat valve.	100
117	Remove & installation of Water pump.	500
118	Checking specific gravity & Battery charge	100
119	Removing & re-installation battery / batteries.	50
120	Replacement of ammeter.	350
121	Replacement of Boost pressure / air temperature sensor.	50
122	Replacement of brake light switch.	50
123	Replacement of Clutch switch.	50
124	Replacement of combination switch.	250
125	Replacement of Coolant temperature sensor.	100
126	Replacement of ECU.	200
127	Replacement of Engine speed sensor.	200
128	Replacement of flasher unit.	100
129	Replacement of front indicator.	50
130	Replacement of horn.	100
131	Replacement of main line switch.	350

132	Electric horn 2v	Each	1	430
133	Electric welding	Each	1	50
134	Element Assy, Fuel	Each	1	1400
135	EML life max oil	Each	1	355
136	Engine Bolt	each	1	120
137	Engine head assy	each	1	9000
138	Engine head gasket	Each	1	2800
139	Engine mounting	Each	1	330
140	Engine oil 15w40	ltr	1	385
141	Engine Oil Filter	No	1	250
142	Engine oil seal	each	1	550
143	Engine pacing	Each	1	150
144	Engine ring	Each	1	200
145	Engine Twining	Each	1	350
146	Engine valve intake	each	1	350
147	Exhaust manifold	Each	1	1900
148	Fan belt	Each	1	2150
149	Feed Pump	Set	1	1400

132	Replacement of oil pressure switch.	150
133	Replacement of tail lamp.	100
134	Replacement of wiper blade.	20
135	Replacement waper motor.	250
136	Removel & replacement of starter pinion	350
137	Overhauling of starter motor.	650
138	Removal and re-installation of alternator.	300
139	Overhauling of alternator.	500
140	Fitting seat cover	500
141	Fixing of front / rear tyre mud flap set.	200
142	Removal and installation of bumper assembly.	500
143	Removal and installation of door lock.	200
144	Removal and installation of driver seat.	100
145	Removal and installation of one fender	150
146	Remove / replace of hood ceiling.	1200
147	Removel & replacement of dash board.	3000
148	Removel & replacement of inner view mirror.	50
149	Removel & replacement of out side rear view mirror.	100

150	Fender liner front left	Each	1	550
151	Fender liner front right	Each	1	550
152	Fender liner rear left	Each	1	450
153	Fender liner rear right	Each	1	450
154	Flate washer	Each	1	20
155	Fly wheel	Each	1	6500
156	Fly wheel ring	Each	1	1800
157	Fog Light	Set	1	350
158	foot mat	Set	1	2400
159	Front bumper	Each	1	3200
160	Front hub bearing inner	Each	1	1250
161	Front hub bearing outer	Each	1	820
162	Front Windshield glass	Each	1	6400
163	Fuel filter	Each	1	180
164	Fuel injection overflow pipe	Each	1	230
165	Fuel injector nozzel	Each	1	1950
166	Fuel injector pipe	Each	1	230
167	fuel pipe	per piece	1	330
168	Fuel pump Assy	Each	1	45000
169	Fuel pump washer	Each	1	10
170	Fuel Supply Pump	Set	1	3200

150	Removel & replacement of sunvisor.	50
151	Replacement of body shield complete	2000
152	Replacement of body side indicator cover.	50
153	Replacement of body side indicator lamp.	50
154	Replacement of bonnet cable.	150
155	Replacement of bonnet lock.	150
156	Replacement of Bonnet.	350
157	Replacement of cargo box locks.	250
158	Replacement of cargo box.	500
159	Replacement of door handle.	50
160	Replacement of door hinges.	150
161	Replacement of door weather strip.	50
162	Replacement of fog lamp assy.	500
163	Replacement of front bumper	500
164	Replacement of license plate cover.	100
165	Replacement of rear bumper	400
166	Replacement of rear view mirror.	100
167	Replacement of window regulator.	250
168	Replacement of windscreen glass gum type	2500
169	Replacement of windscreen glass rubber type	400
170	Apron painting each	200

171	Full Engine Overhauling	Each	1	8500
172	Fuse	No	1	20
173	Fuse 10 Amp	Each	1	10
174	Fuse 15 Amp	Each	1	10
175	Fuse 20 Amp	Each	1	10
176	Fuse 25 Amp	Each	1	10
177	Fuse 30 Amp	Each	1	15
178	Fuse 5 Amp	Each	1	10
179	Gas kit	Each	1	50
180	Gear Box	Set	1	25000
181	Gear box assembly	Each	1	25000
182	Gear box mounting	Each	1	130
183	Gear box oil seal front	Each	1	150
184	Gear box oil seal rear	Each	1	90
185	Gear box packing	Each	1	350
186	Gear counter	Each	1	6500
187	Gear oil	per litre	1	350
188	Gear pinion	Each	1	90
189	Gear pinion 2nd	Each	1	2800
190	Gear pinion shaft	Each	1	350
191	Glow Plug	Set	1	950

171	Bonnet assy. Painting charges	3000
172	Cabin assy. Painting charges	13000
173	Cargo box complete painting (double cabin)	4000
174	Cargo box complete painting (single cabin)	25
175	Cargo box side panting each	2500
176	Cargo box tail gate painting	1500
177	Complete body assy. Painting charges	22000
178	Complete top panel painting charges	4000
179	Door painting each	2500
180	Front bumper assy. Painting charges	2500
181	Lower panel painting each	1500
182	Rear bumper painting charges	1200
183	Side fender assy. Painting each charges	2500
184	Tail gate/dicky painting charges	2500
185	Apron painting each	25
186	Bonnet assy. Painting charges	3200
187	Cabin assy. Painting charges	13000
188	Cargo box complete painting (double cabin)	4000
189	Cargo box complete painting (single cabin)	25
190	Cargo box side panting each	2500
191	Cargo box tail gate painting	2500

192	Glow plug	Each	1	950
193	Grease	per kg	1	500
194	Grease gun	Each	1	1000
195	Half Engine Overhauling	Each	1	3500
196	Hand Brake Cable	Set	1	1250
197	Hand brake cable	Each	1	750
198	Head Gasket	No	1	3800
199	Head light Assy (Left)	Each	1	2100
200	Head light Assy (Right)	Each	1	2100
201	Head Light Bulb	Set	1	250
202	Head light bulb	Each	1	120
203	Head light bulb (Halogen)	Each	1	80
204	Head light cover	Each	1	1200
205	Head light Set	Set	1	450
206	Horn and switch	set	1	600
207	Horn high	Each	1	430
208	Horn low	Each	1	400
209	Horn relay	Each	1	150
210	horn switch	per piece	1	120
211	Hose pipe clamp	Each	1	50
212	Hub Bearing Front Inner	Set	1	1200
213	Hub Bearing Front Outer	Set	1	750
214	Hub Check Nut	Set	1	120
215	Hub greasing (Front)	Each	1	350
216	Hub greasing (Rear)	Each	1	200
217	Hub Oil Seal	Set	1	250

192	Complete body assy. Painting charges	22000
193	Complete top panel painting charges	3500
194	Door painting each	2500
195	Front bumper assy. Painting charges	2500
196	Lower panel painting each	1500
197	Rear bumper painting charges	1200
198	Side fender assy. Painting each charges	2500
199	Tail gate/dicky painting charges	2000

218	Hub Splender	Set	1	2850
219	Hubs bearing	per piece	1	200
220	Hubs checknut	Each	1	200
221	Hubs checknut lock	Each	1	50
222	Hubs oil	Each	1	200
223	Hubs oil seal front	Each	1	200
224	Hydraulic jack (Light Duty)	Each	1	2600
225	Hydraulic jack oil seal (Set of 12 pcs)	Each	1	250
226	Hydraulic oil	per litre	1	250
227	Ignition switch	Each	1	2800
228	Indicator light	Each	1	250
229	Inner door lock (R)	Each	1	450
230	Inner door lock(L)	Each	1	450
231	Intake manifold	Each	1	2100
232	Intake valve	Set	1	2300
233	Jack lever	Each	1	1200
234	Key Lock Set	Set	1	750
235	Kilimeter cable	Each	1	950
236	Link assy front	Each	1	1200
237	Link Bush Front	Pcs	1	40
238	Link Bush Rear	Pcs	1	150
239	Link Rod	Pcs	1	950
240	Link rod Front	Each	1	1200
241	Lock pati	Each	1	10
242	Looking glass (R)	Each	1	1200
243	Looking glass (L)	Each	1	1200
244	Lower bolt joine	Each	1	20
245	LT wire 5mm	Each	1	20
246	LT wire 6mm	Each	1	20
247	LT wire 8mm	Each	1	80

248	Main Bearing	Set	1	1400
249	Main bearing	Each	1	350
250	Main Bearing Oil Seal	Set	1	1750
251	Main leaf spring (R)	Each	1	1850
252	Master cylinder	Each	1	3150
253	Master Cylinder Kit	Set	1	600
254	Master cylinder kit	Each	1	380
255	Mobile	per litre	1	355
256	Mobile (15w40)	per litre	1	385
257	Mobile Filter	No	1	300
258	nozzle pipe	per piece	1	150
259	Number Plate	each	1	350
260	Nut & Bolts	Each	1	40
261	Nuts and Bolts(4 Wheel)	Set	1	250
262	Oil filter	Ltr	1	300
263	Oil Supply Pump	No	1	1500
264	Open end wrench set (6-32mm)	Set	1	1200
265	Pilot bearing	Each	1	550
266	Piston	set	1	6800
267	Piston	Each	1	2800
268	Piston Ring	No	1	3850
269	Plastic lock	Each	1	20
270	Plastic tape	Each	1	10
271	Plastic washer	Each	1	20
272	Power steering bearing	Each	1	450
273	Power Steering Belt	No	1	350
274	Power steering box Assy	Each	1	18300
275	Power Steering Oil	ltrs	1	350
276	Power steering overhauling	Each	1	1200
277	Power steering pipe	Each	1	2280

278	Pressure Plate	Set	1	4800
279	Propeller shaft	Each	1	4000
280	Propeller shaft bolt	Each	1	30
281	PVC tape	Each	1	20
282	Radiator assy	Each	1	8400
283	Radiator cap	Each	1	240
284	Radiator coolant	each	1	280
285	radiator hose pipe lower	Each	1	580
286	Radiator hose pipe upper	Each	1	450
287	Rain guard	Set	1	1200
288	Rear Axle Corn	Set	1	800
289	Rear bush adjust	Each	1	80
290	Rear center bolt	Each	1	100
291	Rear Differential Assy	No	1	18000
292	Rear hub bearing inner	Each	1	730
293	Rear hub bearing outer	Each	1	650
294	Rear second leap	Each	1	1750
295	Rear shackle Assy	Each	1	650
296	Rear shackle pin	Each	1	250
297	rear shocker	Each	1	2650
298	Rear Spring cushion plastic plate	Each	1	250
299	Rear tail board railing	Each	1	1500
300	recovery van hiring charges	Per Km	1	1000
301	Rectifier	Each	1	730
302	Red paper	Each	1	20
303	Relay 2 pin 12v	Each	1	180
304	Relay 3 pin 12v	Each	1	180
305	Relay 4 pin 12v	Each	1	180
306	Relay 5 pin 12v	Each	1	180
307	Release Bearing	Set	1	1200

308	Relese bearing fork	Each	1	320
309	Relese bearing lock	Each	1	230
310	Rocker Arm	Each	1	230
311	Rocker shaft	Each	1	720
312	Rotor coil	Each	1	1200
313	Screw	Each	1	5
314	seat cover	Set	1	6300
315	Seat new making	Set	1	2000
316	Self Armerture 12v	Each	1	1800
317	Self bush 12V	Each	1	180
318	Self Carbon	Set	1	1250
319	Self carbon 12V	Each	1	420
320	Self field coil 12v	Each	1	1200
321	Self housing	Each	1	450
322	Self Overhauling	Each	1	600
323	Self rewinding	Each	1	250
324	Self top cover	Each	1	280
325	Shaft yoke & Teeth	No	1	2950
326	Shakle Pin Assy	set	1	280
327	Shock absorber	Each	1	1400
328	Shock Absorber Bush	set	1	50
329	Shock Absover Front	Set	1	2800
330	Shock Absover Rear	Set	1	2250
331	shocker bush	Each	1	40
332	Shocker nut bolt	Each	1	130
333	Side Light	No	1	250
334	Side Light Bulb	No	1	30
335	Side Light Clamp	Set	1	120
336	Silencer box	Each	1	2450
337	Silencer pipe	Each	1	1200

338	Socket (6mm-32mm)	Set	1	3700
339	Solonoid switch 12v	Each	1	1200
340	Speedo meter Assy	Each	1	2400
341	Speedo meter cable	Each	1	130
342	Speedo meter pinion	Each	1	1100
343	Spring 2nd leaf (R)	Each	1	1650
344	Spring 3rd leaf ®	Each	1	1250
345	Spring 4th leaf ®	Each	1	950
346	Spring 5th leaf ®	Each	1	850
347	Spring 6th leaf ®	Each	1	600
348	Spring buffer mounting	Each	1	350
349	Spring bush	Each	1	100
350	Spring Bush Metal	No	1	220
351	Spring Clamp	No	1	120
352	Spring cycle pin	Each	1	120
353	Spring griping washer	Each	1	50
354	Spring hanger	Each	1	580
355	Spring pin	Each	1	120
356	Spring plate	Each	1	720
357	Spring shackle	Each	1	120
358	Spring washer	Each	1	10
359	Stabilizer Bar Bush - Front	No	1	650
360	Stabilizer link rod	Each	1	1200
361	Starter carbon	Each	1	230
362	Starter coil	Each	1	900
363	Starter relay 12v	Each	1	180
364	Steering adjuster bolt assy	Each	1	120
365	Steering box oil seal	Each	1	450
366	Steering box overhauling	Each	1	1500
367	Steering column (Inner)	Each	1	700

368	Steering column (Outer)	Each	1	720
369	Steering cross	Each	1	480
370	Steering cross bearing	Each	1	650
371	Steering rack end	Each	1	1200
372	Steering wheel cover	No	1	650
373	Suspension arm bush lower small	Each	1	650
374	Suspension arm bush upper small	Each	1	380
375	Synchronizer circlip lock	Each	1	120
376	Synchronizer hub	Each	1	1500
377	Synchronizer lock	Each	1	150
378	Synchronizer ring	Each	1	600
379	Synchronizer sheeve	Each	1	350
380	Synchronizer sheeve iddle bearing	Each	1	1650
381	Tail Inner Bearing	Set	1	450
382	Tail Oil Seal	Set	1	450
383	Tail Outer Bearing	Set	1	720
384	Tail pinion bearing inner	Each	1	1550
385	Tail pinion bearing outer	Each	1	1200
386	Tail pinion checknut washer	Each	1	120
387	Tail pinion checknut	Each	1	220
388	Tail Pinion oil seal	piece	1	450
389	Tail cover packing	Each	1	480
390	Tempering spring	Each	1	150
391	Threading tape	Each	1	20
392	Thrust washer	Each	1	20
393	Tie clip	Each	1	20
394	Tie rod end	Each	1	1200
395	Tie Rod End-Big	Set	1	700
396	Tie Rod End-Small	Set	1	650
397	Timing cover front	Each	1	200

398	Timing cover gear	Each	1	650
399	Timing cover oil seal	Each	1	550
400	Timing pinion chain and adjuster kit set	set	1	250
401	Top shaft bearing	Each	1	1200
402	Transmission half over hauling	Each	1	2000
403	Transmission over hauling	Each	1	3500
404	U bolt nut	Each	1	50
405	U bolt plate	Each	1	850
406	U bolt rear	Each	1	250
407	U bolt rear	Each	1	220
408	U-Bolt	No	1	350
409	Upper bolt joint	Each	1	1200
410	Valve guide	Each	1	150
411	Valve key	Each	1	80
412	valve oil seal	each	1	200
413	Valve spring	Each	1	10
414	Valve washer	Each	1	10
415	washer hat	Each	1	20
416	water pump Assy	Each	1	7800
417	Wheel alignment	Each	1	350
418	Wheel Bearing	Set	1	450
419	Wheel bearing inner front	Each	1	850
420	Wheel bearing inner rear	Each	1	1200
421	Wheel bearing oil seal inner front	Each	1	230
422	Wheel bearing oil seal inner rear	Each	1	680
423	Wheel bearing outer front	Each	1	700
424	Wheel bearing outer rear	Each	1	1200
425	Wheel bolt	Each	1	350
426	Wheel cylinder	Each	1	1850
427	Wheel Cylinder Assy	Set	1	1250

428	Wheel cylinder bucket	Each	1	120
429	wheel Drum	Each	1	3800
430	Wheel nut	Each	1	200
431	Wheel wrench	Each	1	650
432	Wind shield replacing	Each	1	2500
433	Window glass	Each	1	950
434	Wiper Arm	Each	1	400
435	Wiper Blade	Set	1	300
436	Wiper blade	Each	1	240
437	Wiper blade Assy	Each	1	250
438	Wiper motor Assy	Each	1	2800
439	Wiring clip	Each	1	10
440	Zip cock	Each	1	20